REHOBOT®
POWER WITH HYDRAULICS



PHS70-300 PHS80-300

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	443,68 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT801 Gauge	444,74
6	1	AAM18 Gauge adapter	443,80
7	1	O-ring	[A D]
8	1	Spring	[A D]
9	1	Ball	[A D]
11	1	Ball	[A D]
13	1	Ball	[A D]
14	2	Plug	[A D]
15	2	Packing	[A D]
16	1	Washer	[A D F]
17	1	Piston	[D F]
18	1	O-ring	[A D F]
19	1	Supportring	[A D F]
20	1	Wiper	[A D]
21	1	O-ring	[A D]
22	1	Piston	[D F]
23	1	Housing	450,51 [D]
24	1	O-ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1	Ball	[A D]
35	1	Plug	[A D]
36	1	Safety valve PHS70	443,88
36	1	Safety valve PHS80	443,89
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-ring	[A D)
40	1	End plate, front	[E]
41	1	O-ring	[A E]
42	1	Ball	[A E]
43	1	Screw	[E]
44	1	Oil container	[E]
45	1	Plug	[A E]
46	1	Packing	[A E]
47	1	O-ring	[A E]

Pos.	QTY	Description	Part No.
48	1	End plate, rear	[E]
49	1	Yoke	443,70
50	1	Packing	[A E]
51	1	Nut	[A E]
52	1	Label, read manual	[A E]
53	1	Label, release function	[A E]
54	2	Label, REHOBOT	[A E]
54	2	Label, REHOBOT	[A E]
		Repair kit	450,50
		Handle assembly -300	450,52
		Release valve assembly	450,54
		Pump unit Cpl.	450,55
		Tank assembly -300	450,56
		Piston kit	450,57

Eskilstuna-2002-04-29/HGn

[A] Included in Repai kit
[B] Included in Handle assembly
[C] Included in release valve assembly
[D] Included in Pump unit Cpl.
[E] Included in Tank assembly
[F] Included in Piston kit

Always use REHOBOT original spare parts

REHOBOT®

MADE IN SWEDEN

SPARE PART LIST

PHS70/80/100/150-1000 | PHS150-1000L



Subject to change without prior notice!

Document number: 65300 Rev.1.1

Eskilstuna 2017-09-19 DF

REHOBOT Hydraulics AB Skjulstagatan 11 A, 632 29 Eskilstuna, SWEDEN P.O. Box 1107 631 80 Eskilstuna
T. +46 (0)16 - 16 82 00 F. +46 (0)16 - 13 93 16 info@rehobot.se www.rehobot.se

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	44368 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT801 Gauge PHS70/80-1000	444,74
5	1	TX104 Gauge PHS100/150-1000	38831500
5	1	AMT151 Gauge, Ø100 mm PHS150-1000L	45036
6	1	AAM18 Gauge adapter (Not needed for PHS150-1000L)	44380
7	1	O-ring	[A D]
8	1	Spring	[A D]
9	1	Ball	[A D]
11	1	Ball	[A D]
13	1	Ball	[A D]
14	2	Plug	[A D]
15	2	Packing	[A D]
16	1	Washer	[A D F]
17	1	Piston	[D F]
18	1	O-ring	[A D F]
19	1	Supportring	[A D F]
20	1	Wiper	[A D]
21	1	O-ring	[A D]
22	1	Piston	[D F]
23	1	Housing	45051 [D]
24	1	O-ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1	Ball	[A D]
35	1	Plug	[A D]
36	1	Safety valve PHS70	44388
36	1	Safety valve PHS80	44389
36	1	Safety valve PHS100	44390
36	1	Safety valve PHS150	44391
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-ring	[A D)
40	1	End plate, front	[E]
41	1	O-ring	[A E]
42	1	Ball	[A E]
43	1	Screw	[E]

Subject to change without prior notice!
Document number: 65300 Rev.1.1
Eskilstuna 2017-09-19 DF

Pos.	QTY	Description	Part No.
44	1	Oil container	[E]
45	1	Plug	[A E]
46	1	Packing	[A E]
47	1	O-ring	[A E]
48	1	End plate, rear	[E]
49	1	Yoke	44370
50	1	Packing	[A E]
51	1	Nut	[A E]
52	1	Label, read manual	[A E]
53	1	Label, release function	[A E]
54	2	Label, REHOBOT	[A E]
		Repair kit	45050
		Handle assembly PHS70/80/100/150-1000	45058
		Handle assembly PHS150-1000L	45592
		Release valve assembly	45054
		Pump unit Cpl. PHS70- , PHS80-	45060
		Pump unit Cpl. PHS100- , PHS150-	45055
		Tank assembly -1000	45061
		Piston kit PHS70-, PHS80-	45062
		Piston kit PHS100-, PHS150-	45057

[A] Included in Repair kit
[B] Included in Handle assembly
[C] Included in release valve assembly
[D] Included in Pump unit Cpl.
[E] Included in Tank assembly
[F] Included in Piston kit

Always use REHOBOT original spare parts

Subject to change without prior notice!
Document number: 65300 Rev.1.1
Eskilstuna 2017-09-19 DF

REHOBOT®

POWER WITH HYDRAULICS

PHS70-2400 PHS80-2400 PHS100-2400 PHS150-2400



REHOBOT Hydraulics AB Skjulstagatan 11A, 632 29 Eskilstuna, SWEDEN P.O. Box 1107 631 80 Eskilstuna
T. +46 (0)16 - 16 82 00 | F. +46 (0)16 - 13 93 16 | info@rehobot.se | www.rehobot.se

PHS70-2400 PHS80-2400 PHS100-2400 PHS150-2400

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	443,68 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT801 Gauge	444,74
6	1	AAM18 Gauge adapter	443,80
7	1	O-ring	[A D]
8	1	Spring	[A D]
9	1	Ball	[A D]
11	1	Ball	[A D]
13	1	Ball	[A D]
14	2	Plug	[A D]
15	2	Packing	[A D]
16	1	Washer	[A D F]
17	1	Piston	[D F]
18	1	O-ring	[A D F]
19	1	Supportring	[A D F]
20	1	Wiper	[A D]
21	1	O-ring	[A D]
22	1	Piston	[D F]
23	1	Housing	450,51 [D]
24	1	O-ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1	Ball	[A D]
35	1	Plug	[A D]
36	1	Safety valve PHS70	443,88
36	1	Safety valve PHS80	443,89
36	1	Safety valve PHS100	443,90
36	1	Safety valve PHS150	443,91
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-ring	[A D)
40	1	End plate, front	[E]
41	1	O-ring	[A E]
42	1	Ball	[A E]
43	1	Screw	[E]
44	1	Oil container	[E]

Pos.	QTY	Description	Part No.
45	1	Plug	[A E]
46	1	Packing	[A E]
47	1	O-ring	[A E]
48	1	End plate, rear	[E]
49	1	Yoke	443,70
50	1	Packing	[A E]
51	1	Nut	[A E]
52	1	Label, read manual	[A E]
53	1	Label, release function	[A E]
54	2	Label, REHOBOT	[A E]
		Repair kit	450,50
		Handle assembly	450,58
		Release valve assembly	450,54
		Pump unit Cpl. PHS70- , PHS80-	450,60
		Pump unit Cpl. PHS100- , PHS150-	450,55
		Tank assembly -2400	450,63
		Piston kit PHS70-, PHS80-	450,62
		Piston kit PHS100-, PHS150-	450,57

Eskilstuna-2002-12-26/HGn

[A] Included in Repai kit
[B] Included in Handle assembly
[C] Included in release valve assembly
[D] Included in Pump unit Cpl.
[E] Included in Tank assembly
[F] Included in Piston kit

Always use REHOBOT original spare parts

REHOBOT®

POWER WITH HYDRAULICS

65380

PHS240-2400L



PHS240-2400L

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	44368 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT301 Gauge	45037
6	1	O-ring	[A D]
7	1	Spring	[A D]
8	1	Ball	[A D]
9	1	Ball	[A D]
10	1	Ball	[A D]
12	1	Plug	[A D]
13	1	Packing	[A D]
14	1	Wiper	[A D]
15	1	O-ring	[A D]
16	1	Washer	[A D F]
17	1	Bushing	[D F]
18	1	O-ring	[A D F]
19	1	O-ring	[A D F]
20	1	Support ring	[A D F]
21	1	Piston	[D F]
22	1	Piston	[D F]
23	1	Housing	45590 [D]
24	1	O-ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1		[A D]
35	1	Plug	[A D]
36	1	Safety valve Cpl.	45585
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-ring	[A D]
40	1	End plate, front	[E]
41	1	O-ring	[A E]
42	1	Ball	[A E]
43	1	Screw	[E]
44	1	Oil container	[E]
45	1	Plug	[A E]
46	1	Packing	[A E]

Pos.	QTY	Description	Part No.
47	1	O-ring	[A E]
48	1	End plate, rear	[E]
49	1	Yoke	44370
50	1	Packing	[A E]
51	1	Nut	[A E]
52	1	Label, read manual	[A E]
53	1	Label, release function	[A E]
54	2	Label, REHOBOT	[A E]
		Repai kit	45591
		Handle assembly	45592
		Release valve assembly	45054
		Pump unit Cpl.	45593
		Tank assembly	45063
		Piston kit	45594

Eskilstuna-2003-03-06/HGn

[A] Included in Repai kit
[B] Included in Handle assembly
[C] Included in release valve assembly
[D] Included in Pump unit Cpl.
[E] Included in Tank assembly
[F] Included in Piston kit

Always use REHOBOT original spare parts

REHOBOT®

POWER WITH HYDRAULICS

65540

PHS280-2400L



REHOBOT Hydraulics AB Skjulstagatan 11A, 632 29 Eskilstuna, SWEDEN P.O. Box 1107 631 80 Eskilstuna
T. +46 (0)16 - 16 82 00 | F. +46 (0)16 - 13 93 16 | info@rehobot.se | www.rehobot.se

PHS280-2400L

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	44368 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT301 Gauge	45037
6	1	O-ring	[A D]
7	1	Spring	[A D]
8	1	Ball	[A D]
9	1	Ball	[A D]
10	1	Ball	[A D]
12	1	Plug	[A D]
13	1	Packing	[A D]
14	1	Wiper	[A D]
15	1	O-ring	[A D]
16	1	Washer	[A D F]
17	1	Bushing	[D F]
18	1	O-ring	[A D F]
19	1	O-ring	[A D F]
20	1	Support ring	[A D F]
21	1	Piston	[D F]
22	1	Piston	[D F]
23	1	Housing	45590 [D]
24	1	O-ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1	Ball	[A D]
35	1	Plug	[A D]
36	1	Safety valve Cpl.	44913
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-ring	[A D]
40	1	End plate, front	[E]
41	1	O-ring	[A E]
42	1	Ball	[A E]
43	1	Screw	[E]
44	1	Oil container	[E]
45	1	Plug	[A E]
46	1	Packing	[A E]
47	1	O-ring	[A E]
48	1	End plate, rear	[E]
49	1	Yoke	44370
50	1	Packing	[A E]
51	1	Nut	[A E]

Pos.	QTY	Description	Part No.
52	1	Label, read manual	[A E]
53	1	Label, release function	[A E]
54	2	Label, REHOBOT	[A E]
		Repair kit	45591
		Handle assembly	45592
		Release valve assembly	45054
		Pump unit Cpl.	45593
		Tank assembly	45063
		Piston kit	45594

[A] Included in Repai kit
[B] Included in Handle assembly
[C] Included in release valve assembly
[D] Included in Pump unit Cpl.
[E] Included in Tank assembly
[F] Included in Piston kit

REHOBOT®

MADE IN SWEDEN

SPARE PART LIST

PHS70-4100 | PHS80-4100 | PHS100-4100 | PHS150-4100



Subject to change without prior notice!

Document number: 65585 Rev.1.1

Eskilstuna 2014-09-29 DF

REHOBOT Hydraulics AB Skjulstagatan 11 A, 632 29 Eskilstuna, SWEDEN P.O. Box 1107 631 80 Eskilstuna
T. +46 (0)16 - 16 82 00 F. +46 (0)16 - 13 93 16 info@rehobot.se www.rehobot.se

PHS70-4100 PHS80-4100 PHS100-4100 PHS150-4100

Pos.	QTY	Description	Part No.
1	1	Handle	[B]
2	1	Handle grip	44368 [B]
3	4	Track ring	[A B]
4	2	Axle	[B]
5	1	AMT801 Gauge PHS70- PHS80-	44474
5	1	TX104 Gauge PHS100-	38831500
6	1	AAM18 Gauge adapter	44380
7	1	O-Ring	[A D]
8	1	Spring	[A D]
9	1	Ball	[A D]
11	1	Ball	[A D]
13	1	Ball	[A D]
14	3	Plug	[A D]
15	3	Packing	[A D]
16	1	Washer	[A D F]
17	1	Piston	[D F]
18	1	O-Ring	[A D F]
19	1	Supportring	[A D F]
20	1	Wiper	[A D]
21	1	O-Ring	[A D]
22	1	Piston	[D F]
23	1	Housing	45051 [D]
24	1	O-Ring	[A D]
25	1	Piston	[A D]
26	1	Spring	[A D]
27	1	Packing	[A D]
28	1	Plug	[A D]
29	1	Screw	[C D]
30	1	O-Ring	[A C D]
31	1	Release screw	[C D]
32	1	Knob	[C D]
33	1	Screw	[C D]
34	1	Ball	[A D]
35	1	Plug	[A D]
36	1	Safety valve PHS70	44388
36	1	Safety valve PHS80	44389
36	1	Safety valve PHS100	44390
36	1	Safety valve PHS150	44391
37	1	Intake pipe	[A D]
38	1	Strainer	[A D]
39	1	O-Ring	[A D)
40	1	End plate, front	[E]
41	2	Packing	[A E]
42	12	Screw	[E]

Pos.	QTY	Description	Part No.
43	1S	crew	[E]
44	1O	il container	[E]
45	1P	lug	[A E]
46	1P	acking	[A E]
48	1E	nd plate, rear	[E]
49	1Y	oke	44370
51	2L	abel, REHOBOT[	A E]
52	1L	abel, read manual[	A E]
53	1L	abel, release function	[A E]
		Repair kit	50739
		Handle assembly	45058
		Release valve assembly	45054
		Pump unit Cpl. PHS70- , PHS80-	45060
		Pump unit Cpl. PHS100-, PHS150-	45055
		Tank assembly -4100	50616
		Piston kit PHS70-, PHS80-	45062
		Piston kit PHS100-, PHS150-	45057

[A] Included in Repai kit
[B] Included in Handle assembly
[C] Included in release valve assembly
[D] Included in Pump unit Cpl.
[E] Included in Tank assembly -4100
[F] Included in Piston kit

Always use REHOBOT original spare parts